

Message and Assignment Display

Message and assignment is a display mode used in conjunction with the Alias feature and the C Plus III multiple window display. The serial output is also affected by this display type selection.

C Plus III Display

If Message and Assignment is selected for a C Plus III, the second display will show the message type received and the assignment field programmed for the associated ANI ID in the Alias table. An example is below:



In this example, the Message type received was a “*Man Down*” and the assignment field for the received ID was “*Building 13 floor 5*”. The alias was “*CHIEF 28*”.

If Scrolling display mode had been selected, the primary display would alternate between the message type (Man Down) and the received alias. But because the message type is shown in the secondary display, the primary display will show the alias and not flash.

C Plus II Display

The C Plus II does not have a secondary display. Because of this, if a C Plus II is programmed for Message and Assignment, neither the message nor assignment is displayed so the user will not know what type of message was received. The primary display will not alternate between received alias and message type.

Serial Output

If the C Plus serial output is programmed for Cimarron Standard, and the unit is in Message and Assignment mode, the output will include the assignment field.

Special Requirements:

The Message and Assignment feature is enabled in the C Plus personality programming under *Select Display Type*. The optional feature “Alias” must be purchased and activated. Contact Cimarron Technologies for information.

A valid Alias table must be loaded into the C Plus

See Also:

Alias

Communicating with the C Plus using Hyperterm

Scrolling Display